

DSTV SETTINGS FOR SINGLE VIEW DECODERS ON A ONE CABLE SYSTEM

Using the remote of the Dstv, press MENU then
Go to ADVANCED OPTIONS – press OK
Go to DISH INSTALLATIONS press OK
Pin code 9949



Home Network Dstv IS7 - remains as is
(Frequency should be **11594** and Symbol rate **27500** – **do not change these**)

Select IS7 on the required network by pressing the right key on the remote control

Network 2 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **11210** – press OK (11210 not currently being used)
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Network 3 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **11250** – press OK
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Network 4 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **11290** – press OK
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Network 5 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **11330** – press OK
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Network 6 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **11370** – press OK
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Network 7 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **11410** – press OK
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Network 8 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **10930** – press OK
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Network 9 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **10890** – press OK
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Network 10 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **10850** – press OK
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Network 11 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **10810** – press OK
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Network 12 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **10770** – press OK
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Network 13 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **10730** – press OK
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Go to SCAN ALL NETWORKS

If this did not help, go to FACTORY RESET, then redo above steps.
Should you experience further problems, please contact your body corporate delegate.