

DSTV SETTINGS FOR ONE CABLE SYSTEM

Using the remote of the Dstv, press MENU then
Go to ADVANCED OPTIONS – press OK
Go to DISH INSTALLATIONS press OK
Pin code 9949



Network 1 Dstv IS7 - remains as is
(Frequency should be **11594** and Symbol rate **27500** – **do not change these**)

Network 2 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **11210** – press OK
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Network 3 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **11250** – press OK
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Network 4 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **11290** – press OK
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Network 5 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **11330** – press OK
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Network 6 Dstv IS7 – press OK
Go to FREQUENCY – press OK
Left key to remove numbers, then enter **11370** – press OK
Go to SYMBOL RATE – press OK
Left key to remove numbers, then enter **30000** – press OK
Go to USE NIT – right key to **SMATV**
Go to ACCEPT ALL DISPLAYED VALUES & LEAVE SCREEN

Go to SCAN ALL NETWORKS

If this did not help, go to FACTORY RESET, then redo above steps.
Should you experience further problems, please contact your body corporate delegate.